

Dati tecnici

Lubrificazione consigliata:
Olio per utensili pneumatici

Applicazioni:
Banchina, assi e legno pressato, carpenteria pesante, coperture esterne & giardini, capannone, protezioni e fondamenta, legno per murature, applicazioni di metalli su legno.
.

Sistema di funzionamento:
Funzionamento a martello

Caricamento

- 1.Sbloccare la chiusura per aprire porta e caricatore.
- 2.Regolare il livello del caricatore in modo che i chiodi siano allineati con la linea guida.
- 3.Caricare i chiodi dall'alto del caricatore dentro il sistema di alimentazione.
- 4.Chiudere il caricatore e assicurarsi che il chiavistello sia chiuso correttamente.

Technical data

Recommended lubrications:
Pneumatic tool oil

Applications & suitability:
Warf docks, boardwalks, hardwoods & pressure treated lumber, heavy-duty framing, exterior decks & landscaping, pole barns, barriers and foundations, wood to concrete/masonry, some metal to wood application.


Actuating system:
Bump actuation

Filling the magazine

- 1. Release latch to open the door and magazine.
- 2. Adjust the level of the magazine base so that the nails will feed in line with guides.
- 3. Load nails onto pivot in the magazine and full forward so that the nails are inserted into the feeder mechanism.
- 4. On closing the magazine ensure the latch is closed properly.



195MV80_V80_090915 IV



Manuale d'uso, manutenzione e parti di ricambio Parte 2
Use, maintenance and spare parts manual Part.2


V80
cod. 195MV80

Indice di modifica
Upgrade number




0

Accessori a richiesta - Upon request accessories


Supporto bilanciere
Tool hanger



Dotazioni - Equipment





Tipo di punto
Type of fastener



omer s.p.a.
Via Foresto, 42 - 31058 SUSEGANA (TV) ITALY
Tel. 0438 455 318 Fax 0438 455 530
e-mail: omer@omer.it www.omer.it

Ref. No.	Part No.	Description
----------	----------	-------------

001	2MCN3383-A101	Counter Sunk Screw
002	2MV80-A002	Deflector
003	2MV57-A003	Washer
004	2MV80-A004	Hex. Soc. Hd. Bolt
005	2MV80-A005	Protection
006	2MV80-A006	Cap
007	2MV80-A007	Gasket
008	2MV57-A007	Ring
009	2MV80-A009	Bumper
010	2MV57-A009	Compression Spring
011	2MV57-A011	O-Ring
012	2MV80-A012	O-Ring
013	2MV80-A013	Head Valve Piston
014	2MV80-A014	Driver Unit
015	2MV80-A015	O-Ring
019	2MCN2970-A115	Collar
020	2MV80-A020	Cylinder
022	2MV80-A022	Cylinder Band
023	2MV80-A023	Cylinder Ring
024	2MV80-A024	O-Ring
025	2MCN2970-A121	Bumper-A
026	2MCN2970-A122	Bumper-B
027	2MCN2970-A442	Bolt Cap
028	2MV57-A025	Spring Cover
029	2MV80-A029	Safety
030	2MV80-A030	Safety Spring
031	2MV80-A031	Pin-Nail Stop
032	2MV80-A032	Door
033	2MCN3165-A211	Spring Pin
034	2MV80-A034	Latch Spring
035	2MCN2970-A413	Door Latch
036	2MV80-A036	Pin
037	2MCN2970-A419	Nail Stop
038	2MV80-A038	O-Ring
039	2MV80-A039	Hex. Soc. Hd. Bolt
040	2MV80-A040	Nose Piece
041	2MV80-A041	O-Ring
042	2MCN2970-A123	Grommet A
043	2MCN2970-A124	Door Shaft Pin
044	2MCN3165-A126	Spring Pin
045	2MCN2970-A435	Pin Feed Piston
046	2MCN2970-A437	Feed Finger Spring
047	2MV80-A047	Feed Finger
048	2MV80-A048	Feed Piston
049	2MV80-A049	Feed Finger Spring
050	2MV80-A050	Feed Bumper
051	2MV80-A051	Feed Piston Cap
052	2MCN2970-A411	C-Ring
054	2MCN2970-A416	Pu Retainer
055	2MV80-A055	O-Ring
056	2MV80-A056	O-Ring
057	2MV80-A057	Body
058	2MCN2970-A402	O-Ring
059	2MV57-A084	Trigger Valve Head
060	2MV57-A065	Plunger
061	2MV57-A066	O-Ring
062	2MV57-A064	Spring
063	2MV57-A061	Valve Plunger
064	2MV57-A063	O-Ring
065	2MV57-A060	O-Ring
066	2MV57-A062	O-Ring
067	2MCN2970-A211	Pin
068	2MV57-A070	Plunger Cap
069	2MV57-A067	O-Ring
070	2MV57-A069	O-Ring
071	2MCN2970-A425	Safety Guide
073	2MV80-A073	Roll Pin
074	2MV80-A074	Roll Pin
075	2MV80-A075	Handle Grip
076	2MV57-A057	Secondary Trigger
077	2MV57-A056	Trigger
078	2MCN3165-A216	Spring Pin
079	2MV80-A079	Filter
080	2MV80-A080	End Cap
081	2MV80-A081	O-Ring
082	2MV80-A082	C-Ring
083	2MV80-A083	Magazine Cover
084	2MV80-A084	Spring Base
085	2MV80-A085	Spacer
086	2MV57-A073	Spring
087	2MV80-A087	Magazine Post
088	2MV57-A089	Washer
089	2MV57-A072	Spring Base



090	2MCN2970-A443	Magazine Shaft Pin
091	2MV80-A091	Magazine Case
092	2MV80-A092	Washer
093	2MV80-A093	Hex. Soc. Hd. Bolt
094	2MCN2970-A123	Grommet A
095	2MV80-A095	Dusty Cover
096	2MV80-A096	Dust Shield Plug
097	2MV57-A080	Washer
098	2MV80-A098	Feed Piston Spring
099	2MV80-A099	Spring Pin
100	2MV80-A100	Washer
102	2MV57-A087	Pu Retainer
103	2MV80-A103	Pin
104	2MCN2970-A103	Grommet
105	2MCN2970-A110	Washer
106	2MV80-A106	O-Ring
107	2MV57-A094	Bush
110	2MV57-A100	Trigger Valve Assy

